



MAINTENANCE

MODE SELECTOR RING (#177 & #178)

Replace a worn Mode Selector Ring or change to the PRO version. If the light is dirty, we recommend rinsing it under running water and drying it before changing the mount.

PLEASE NOTE:

The light must not be opened when under water.



1. Use the Service Tool¹ to unscrew the light.




2. Carefully remove the o-ring.



3. Remove the mount.



4. Remove the old Mode Selector Ring.



5. Mount the new Mode Selector Ring onto the lens.



6. Place the mount back on top of the guide pins.²



7. Place the o-ring back in its groove³.



8. Use the Service Tool to screw the light back together.

¹ The Service Tool is included in all Orbiloc Safety Lights produced from 2020 and all Service Kits produced from 2019.

² Pressing the mount over the o-ring may damage both parts. Therefore, we recommend placing the mount before the o-ring.

³ If the Safety Light is dirty, we recommend cleaning the o-ring groove with a cotton bud or clean tissue.